

# 90x150 (90x50)

## DX3E Teeny

 **EAGTAC**  
<http://www.eagtac.com>




Runtime	0.6-150 hrs
Battery	3.7V Li-Po 400mAh
Charging	USB 1A or higher

### Quick Start

Turn flashlight on \*with thermal management

- 1) Low level: Press once
- 2) Medium level: Click once
- 3) High Level (40%)\*: Double click once
- 4) Max level (100%)\*: Double click twice

Change brightness output (memory) (Press and hold)



Access AUX levels

Press and hold for 6 seconds at medium level

Lock and unlock flashlight

Press and hold for 4 second from off.

Toggle blink locator

Lock flashlight, then click 10 times to toggle.

Battery report

Blink	Capacity
4	70%-100%
3	40-70%
2	10%-40%
1	<10%

Video Demonstration & more



[support.eagtac.com](http://support.eagtac.com)

### Read and Agree Safety Warning Before Use

This flashlight has built-in high capacity Li-Po rechargeable battery which can catch on fire or cause explosion if disassembled, shorted, or exposed to high temperature.

Do not submerge flashlight under water. Do not drop or crush. Do not point flashlight to anyone. Keep away from children or elderly. Only charge flashlight on fire-proof surface. Never leave flashlight running or charging unattended.

To prevent unwanted accidental activation, lockout flashlight by pressing and hold 4 seconds while flashlight is off.

When the output starts to dim or flashlight reports low voltage, charge battery soon. Further discharge or prolonged storage of an empty battery will shorten the battery life.

### Product Warranty

For repair, replacement, or other inquiries contact your EAGTAC dealer. You can also reach our customer support via email: [support@eagtac.com](mailto:support@eagtac.com).

We warrant this flashlight to be free from defects in workmanship and materials. We will repair, replace at our option, without charging any product or part which is found to be defective under normal use within 1 year from the date of purchase with the proof of purchase.

This warranty does not cover normal wear and tear. It also does not apply to any products or parts which have been subject to modification, misuse, abuse, negligence, accident, improper maintenance, water damage, or battery leakage. See our product support page for details.